



## RooSy inspection window



Without blinds



Raise and lower the blinds



Turn over the blinds

### Inspection window consist of :

2x thermally toughened single-pane safety glass ESG-H with circulating screen printing in RAL9016 or RAL9006.

Between the two window panes is a 4-parted intermediate frame out of polished stainless steel which circumferentially seals the glass elements.

Blinds are possible.

Radiation protection glasses up to 3,5mmPb are optional possible.



Radiation protection glass	Glass thickness	Lead equivalent bei 100kV	Maximal dimension
RD30	6mm	0,5mm	1.200x1.600mm
RD50	5-6,5mm	1,5mm	1.100x1.800mm
RD50	7-8,5mm	2,1mm	1.100x1.400mm

### Visual protection:

- Electric blinds**

Aluminium blinds 50mm, DC motor 24V with automatic end switch,

- Laser protection blind**

Special laser protection construction, with side-guided rails and blinds without holes

- Electrical roller blind**

Raise and lower the bild, roller blind motor 230V-AC

